

850CH-2 / G3CH-2 2/8-Slot Charger

850CH-2 / CH-8 CHARGER For RU-850LTH & RU-850LTB & R-4THA & R-4TB


G3CH-2 / CH-8 CHARGER For RU-G3TH & RU-G3TB & R-4TBM & UF-20TB

JT5[®] PROFESSIONAL CO., LTD. No. 148, 9th Industry Road, Ta-Li Industrial Park, Taichung City, Taiwan, R.O.C.

Tel: 886-4-24938803 Fax: 886-4-24914890 E-mail: jts@jts.com.tw



1. Parts Identification






0

Rechargeable battery (4 rechargeable battery included with CH-2 / 16 rechargeable battery included with CH-8)





(8-Slot Charger)

2. Specification

CH-2 (2-Slot Charger) Input: AC 100~240V, 0.4A max Output: DC 12V, 1A

LED Indicator Full Charged / Standby: Green Charging: Flash Green Fault: Flash Red

Charging Time: 5 hours (2000mAh rechargeable battery)

3. Charge Battery

CH-8 (8-Slot Charger) Input: AC 100~240V, 1.2A max Output: DC 15V, 3A

LED Indicator Full Charged / Standby: Green Charging: Flash Green Fault: Flash Red

Charging Time: 5 hours (2000mAh rechargeable battery)


Plug the RU-G3TH / RU-G3TB / RU-850LTH / RU-850LTB / R-4THA / R-4TB / R-4TBM / UF-20TB into "Charger Slot" CH-2 or CH-8.

The charging indicator will flash green light when it is charging, and the green light will stop flashing when it is fully charged.

Noted 1: As soon as AC power is connected, the charging indicator will show green light.

Noted 2: Please follow the direction and push the transmitters to the end

till it touch the charging point as show in below demonstration picture. Noted 3: One charger Slot can only charge one item at a time.



850CH-2 / G3CH-2 2/8-Slot Charger 850CH-2 / CH-8 CHARGER For RU-850LTH & RU-85