



LED Dot Laser



Технические параметры

1. Рабочее напряжение: AC95V-245V 50/60Hz
2. Мощность: 20 Вт (волшебный шар 15 Вт, красно-зеленый лазер 30 мВт)
3. Параметры освещения: 1 шт. 15 Вт OSRAM 4-в-1 светодиод, зеленый лазер 30 мВт, красный лазер 100 мВт
4. Режим управления: Международный DMX512, 12 каналов
5. Режим работы: DMX512, ведущий/ведомый, автономный, голосовое управление
6. Режим затемнения: 0-100% сверхплавное затемнение

2. DMX каналы

12channel	function	DMX value	description
1	Magic motor	0-255	0-127 rotation position 0-180 degrees, 128-255 motor self-rotation from fast to slow
2	Rotation amplitude	0-255	Control motor self-moving range 0-255 (0-150 degrees) channel 1 is more than 128 effective
3	Laser motor	0-255	0~9(stop)10~255 from slow to fast
4	Dimmer	0-255	Linear dimming from dark to light
5	Strobe	0-9	None
		10-255	Strobe from slow to fast
6	R dimmer	0-255	Red LED from dark to bright
7	G dimmer	0-255	Green LED from dark to bright
8	B dimmer	0-255	Blue LED from dark to bright
9	W dimmer	0-255	White LED tones from dark to bright
10	R laser dimmer	0-255	Red laser from dark to bright

11	G laser dimmer	0-255	Green laser from dark to bright
12	Macro function control	0-50	Channel 1 to channel 11 is valid
		51-150	Auto run
		150-255	Voice

3. Описание меню дисплея

Number	Menu	Value Range	Description
1	A001	001-512	DMX512 Address setting
2	A1-9	1-9	Red Auto Mode, Motor speed from slow to fast
3	A2-9	1-9	Green Auto Mode, Motor speed from slow to fast
4	A3-9	1-9	Blue Auto Mode, Motor speed from slow to fast
5	A4-9	1-9	White Auto Mode, Motor speed from slow to fast
6	A5-9	1-9	Laser Auto Mode, Motor speed from slow to fast
7	A6-9	1-9	Macro Auto Mode, Motor speed from slow to fast
8	S1-9	1-9	Voice 1 Mode, Sensitivity from small to large
9	S2-9	1-9	Voice 2 Mode, Sensitivity from small to large

4. Описание кнопок

Нажмите кнопку MENU для изменения режима меню, нажмите кнопки UP или DOWN для изменения значения, нажмите кнопку ENTER для сохранения, автоматическая заставка экрана включается через 30 секунд после нажатия любой кнопки, нажмите любую кнопку для активации

экрана.