



OWNER'S MANUAL

Before operating, please read this manual completely.



PA2183M
Monitor Panel




FEATURES

- | 10CH inputs.**
- | Volume control.**
- | A display screen is provided for the quick and easy visual monitoring of input level.**
- | Build in monitor speaker.**

Left blank for memo




FRONT PANEL




- ① Power switch
- ② Power LED indicator
- ③ Monitor Speaker
- ④ Display screen
- ⑤ Left shift key
- ⑥ Right shift key
- ⑦ Volume control

REAR PANEL



- ① 1~10CH input terminals
- ② AC Power cord
- ③ AC Fuse.

CONNECTIONS



OPERATION

- 1 Make connections as shown above then turn on the power.
- 2 Select channel which you want to monitor with **Right shift key** or **Left shift key**. Speaker on the front panel will sound with a red LED lit.
- 3 Control the volume with **Volume controller** on front panel. The level of every channel doesn't regard the volume.

SPECIFICATIONS

Channels	10, switchable
Inputs	70 ~ 100 V , 10 k Ω
Output	65 dB SPL Variable
Frequency response	100 Hz--15 kHz
Signal to noise ratio	80 dB
Speak	Build in
Protection	AC fuse \times 1
Power Requirement	AC 220 –240 V / 50~60 Hz
Dimensions	485 \times 88 \times 378 mm
Gross weight	6.5 kg
Net weight	5.2 kg

Specifications are subject to be changed without notice.

CAUTION

- Do not put the vase full of water and similar things on the machine.
- Please pull out the plug from the outlet when the machine is OFF state.
- To reduce the risk of electric shock, do not remove the unit's cover.

No user parts are inside. For services, refer to a qualified service person.